

ModusToolbox™ Power Conversion Configurator user guide

ModusToolbox™ Industrial MCU Technology Pack version 2.0.0

Power Conversion Configurator version 1.0.0

About this document

Scope and purpose

The Power Conversion Configurator is a tool included with the ModusToolbox™ software intended to generate data structures to configure middleware for provided power-supply design inputs. The tool provides a reference for estimating and demonstrating the typical behavior of a converter.

Intended audience

This document helps application developers understand how to use the Power Conversion Configurator as part of creating a ModusToolbox™ application.

Document conventions

Convention	Explanation
Bold	Emphasizes heading levels, column headings, menus and sub-menus
<i>Italics</i>	Denotes file names and paths.
<code>Courier New</code>	Denotes APIs, functions, interrupt handlers, events, data types, error handlers, file/folder names, directories, command line inputs, code snippets
File > Open	Indicates that a cascading sub-menu opens when you select a menu item

Abbreviations and definitions

The following define the abbreviations and terms used in this document:

- ADC – analog-to-digital conversion
- Buck – A buck converter or step-down converter is a DC-to-DC converter that decreases voltage while increasing current from its input (supply) to its output (load).
- CMP – comparator
- Configurator – A GUI-based tool used to configure a resource.
- DAC – digital-to-analog conversion
- HS/LS – High/Low side
- ISR – interrupt service routine
- PCCM – Peak Current control mode
- PWM – pulse width modulation
- VCM – Voltage control mode

About this document

Reference documents

Refer to the following documents for more information as needed:

- [ModusToolbox™ tools package user guide](#)
- [Eclipse IDE for ModusToolbox™ user guide](#)
- [VS Code for ModusToolbox™ user guide](#)
- [Device Configurator user guide](#)
- [LCS Manager CLI user guide](#)

Table of contents

Table of contents

- 1 Overview..... 4**
- 1.1 Supported middleware4
- 2 Launch the Power Conversion Configurator 5**
- 2.1 From the Device Configurator.....5
- 2.2 make command5
- 2.3 VS Code and Eclipse6
- 2.4 Standalone executable6
- 3 Quick start..... 7**
- 4 Code generation..... 8**
- 5 GUI description 9**
- 5.1 Menus.....9
- 5.2 Toolbar9
- 5.3 Notice List.....10
- 5.4 Status bar10
- 5.5 Logging10
- 6 Tabs/Parameter configuration.....11**
- 6.1 Converter tab.....11
- 6.2 Modulator tab.....14
- 6.3 ADC tab16
- 6.4 Controller tab17
- 6.5 Bode plot19
- 7 Version changes21**


Overview

1 Overview

The Power Conversion Configurator provides the capabilities to initially configure a buck topology. Various parameters such as input voltage, output voltage, output current, passive components, protection, and control parameters are easily configured in the user-friendly interface. Subsequently, the Configurator generates a basic schematic diagram, a Bode plot for user reference, and calculates the controller coefficient values to facilitate the execution of a control loop in firmware implementation.

Note: The equations used in this tool are approximations. Real-world application conditions (PCB properties, components used, layout routing, cooling, etc.) may impact results.

Note: The software was tested with PSoC Control C3M3 Dual Buck Evaluation Kit (24 V DC input voltage).



1.1 Supported middleware

The Power Conversion middleware uses configuration setups developed in the Power Conversion Configurator GUI or with external applications.

Name	Version	Link
Power Conversion Middleware (mtb-pwrconv)	1.0	https://github.com/Infineon/mtb-pwrconv

Launch the Power Conversion Configurator

2 Launch the Power Conversion Configurator

There are several ways to launch the Power Conversion Configurator, and those ways depend on the application, and how you use the various tools.


Note: After you create a new project, at first use the Library Manager to add the `mtb-pwrconv` library and use the Device Configurator to add a Buck Converter. Further, you can open the Power Conversion Configurator in any below-described way.

2.1 From the Device Configurator

You can launch the Power Conversion Configurator by using the Device Configurator. The Device Configurator displays information based on the `design.modus` file. When you open the Power Conversion Configurator from the Device Configurator, information about the device and the application is passed to the Power Conversion Configurator. When you save changes in the Power Conversion Configurator, it updates the `design.modus` file and [generates code](#).

Launch the Device Configurator. (For details, refer to the [Device Configurator user guide](#).)

On the **Solutions** tab:



1. Add a **Buck Converter**.
2. Configure the hardware parameters.
3. On the **Parameters** pane, click the **Launch Power Conversion Configurator** button.
4. For multiple solutions (up to 4): select a respective solution and do step 3.

2.2 make command

As described in the [ModusToolbox™ tools package user guide](#) "ModusToolbox™ build system" chapter, you can run numerous `make` commands in the application directory, such as launching the Power Conversion Configurator. Create a ModusToolbox™ application, navigate to the application directory, and type the following command in the appropriate bash terminal window:

```
make power-conversion-configurator
```

This command opens the Power Conversion Configurator GUI for the specific application in which you are working.

Launch the Power Conversion Configurator

2.3 VS Code and Eclipse

VS Code and Eclipse have tools to launch the Power Conversion Configurator from within an open application. Refer to the applicable user guide for more details:


- [VS Code for ModusToolbox™ user guide](#)
- [Eclipse IDE for ModusToolbox™ user guide](#)

2.4 Standalone executable

You can launch the Power Conversion Configurator by running its executable as appropriate for your operating system (for example, double-click it or select it using the Windows **Start** menu). By default, the Configurator is installed here:

```
<install_dir>/ModusToolbox/packs/ModusToolbox-Industrial-MCU-Pack/tools/power-conversion-configurator
```

When launched this way, the Power Conversion Configurator opens blank. Open an existing *.modus file that is already supporting the solution personality information.



See [Menus](#) for more information.

Quick start

3 Quick start

This section provides a simple workflow for how to use the Power Conversion Configurator.

1. Create a project for a PSOC™ Control BSP using the Project Creator.
2. If the `mtb-pwrconv` library is not present in the project, use the Library Manager to add it.
3. Use the Device Configurator to add a Buck Converter on the **Solutions** tab and configure the hardware.
4. [Launch the Power Conversion Configurator](#).
5. Configure the parameters as required.
6. Save the configuration. See [Code generation](#).
7. Open the Device Configurator and configure peripherals if required.
8. Use the generated structures from `cycfg_pwrconv.h` and `cycfg_pwrconv.c` files as input parameters for functions in your application.

Code generation

4 Code generation

The Power Conversion Configurator relevant firmware will appear in the *cycfg_pwrconv.h* and *cycfg_pwrconv.c* files. The generated files are located in the *GeneratedSource* folder next to the **.modus* file, which contains the user configuration.

GUI description

5 GUI description

The Power Conversion Configurator GUI contains menus, toolbar, and tabs to configure the power converter settings and a Notice List to provide indications.

5.1 Menus

5.1.1 File

- **Open...** – Opens the folder with the configuration file.
- **Close** – Closes the configuration file.
- **Save** – Saves the existing configuration.
- **Open in System Explorer** – Opens your computer's file explorer tool to the folder that contains the *.modus file.
- Recent files – Shows recent files that you can open directly.
- **Exit** – Closes the configurator.

5.1.2 Edit

- **Undo** – Undoes the last action or sequence of actions.
- **Redo** – Redoes the last undone action or sequence of undone actions.
- **Converters** – Displays the available converters.

5.1.3 Settings

- **Local Content** – Select this to toggle between the online and LCS mode, and read the local copy of the manifest file installed from the LCS Manager. Refer to the [LCS Manager CLI user guide](#) for more details.
- **Proxy settings...** – Opens a dialog to specify direct or manual proxy settings.

5.1.4 View


- **Notice List** – Shows/hides Notice List.
- **Bode plot** – Shows/hides the dock window with the bode plot.
- **Toolbar** – Shows/hides the toolbar.
- **Reset View** – Resets the view to the default.

5.1.5 Help

- **View Help** – Opens this document.
- **About Power Conversion Configurator** – Opens the About box for version information, with links to open <https://www.infineon.com> and the current session log files of the application and hardware configuration server.

5.2 Toolbar

The toolbar contains common commands from the [File](#) and [Edit](#) menus. Use the check box under the **View** menu to show or hide the toolbar.



GUI description

The number of available converters depends on the configuration. The user can select a converter to configure by selecting it from the dropdown menu.


5.3 Notice List

The **Notice List** pane combines notices (errors, warnings, tasks, and notes) from many places in the configuration into a centralized list. If a notice shows a location, you can double-click that entry to display the parameter causing the error or warning.

For more information, refer to the [Device Configurator user guide](#).

5.4 Status bar

The **Status bar** displays various input field ranges, etc. On the right side – MCU hardware resources reserved across all instantiated converters. On the left side – currently-edited parameter's name, units, and range.



5.5 Logging

The configurator automatically generates a log for each session. The file location differs for each operating system and can be found in the **About** dialog.


Tabs/Parameter configuration

6 Tabs/Parameter configuration

- [Converter tab](#)
- [Modulator tab](#)
- [ADC tab](#)
- [Controller tab](#)
- [Bode plot](#)

6.1 Converter tab

The **Converter** tab performs configuration of the general converter parameters.



6.1.1 Control mode


There are two control modes for the buck converter to regulate the output voltage:

- **Voltage** – Regulates the output voltage by using only the output voltage itself.
- **Peak Current** – Regulates the output voltage by using the output voltage and high-side switch current as control parameters.

6.1.2 Schematic diagram parameters

Click the green items on the schematic diagram to edit correspondent parameters: **Vin (42V)**, **L (33µH)**, **Iout 2A**, **Vout (12V)**, **C(440µF)**.


6.1.2.1 Input Voltage (Vin)



Tabs/Parameter configuration


Parameter	Description	Range	Default
Input voltage	Converter input voltage	9-800 V	24 V
Minimum	Minimum possible value of converter input voltage	9-800 V	20 V
Maximum	Maximum possible value of converter input voltage	9-800 V	28 V

6.1.2.2 Output Voltage (Vout)




Parameter	Description	Range	Default
Output voltage	Target converter output voltage	2.5-240 V	5 V
Minimum	Minimum possible value of converter output voltage	2.5-240 V	4 V
Maximum	Maximum possible value of converter output voltage	2.5-240 V	6 V

6.1.2.3 Output Current (Iout)



Parameter	Description	Range	Default
Output current	Target converter output current	0.1-20 A	2 A


6.1.2.4 Inductance (L)



Parameter	Description	Range	Default
Inductance	Inductance value	0.1 - 1000000 μH	33.0 μH
ESR	Equivalent series resistance of inductor	0.1 - 1000000 mΩ	30 mΩ

Tabs/Parameter configuration


6.1.2.5 Capacitance (C)



Parameter	Description	Range	Default
Capacitance	Capacitance value	0.1 - 1000000 µF	440 µF
ESR	Equivalent series resistance of capacitor	0.1 - 1000000 mΩ	75 mΩ

6.1.2.1 Sensor

The sensor parameters are available only in **PCCM**.



Parameter	Description	Range	Default
Current sense gain	Equivalent transducer gain to transform current to voltage (e.g. shunt resistance in ohms)	0.001 - 100 V/A	1 V/A

6.1.3 Control parameters

The **Control parameters** group provides options to enter the required values.

Parameter	Description	Range	Default
Number of phases	Number of converter interleaving phases	1 - 4	1
Control loop divider Note: Read only for the current release.	Fast control loop frequency divider	1 - 255	1
Switching freq	Target switching frequency of power switch operation	50000 - 2000000 Hz	200000Hz
Time delay	Time expressed in fraction of PWM period to account for the inherent delay introduced by digital implementation: from analog sensing to duty cycle update. Such a delay is compensated in phase margin determination.	0 - 10.0	1.0
Crossover freq*	Target crossover frequency	2000 - 200000 Hz	10000 Hz
Phase margin*	Target phase margin	10 - 90	50

* The maximum valid values for the **Crossover frequency** and **Phase margin** depend on the entered parameters. They display in the respective parameter tooltip.

6.1.4 Compensation settings (poles and zeros)

The **Compensation settings (poles and zeros)** are the characteristic of the transfer function of the converter's control system. They can be either calculated automatically or set manually. The compensator type may be

Tabs/Parameter configuration

Type III (**VCM**) or Type II (**PCCM**). The number of poles and zeros aligns correspondingly with the selected Control mode.

Parameter	Range	Default
Pole at origin (Hz)	0 - 1e+09	487.841
Pole 1 (Hz)	0 - 1e+09	4822.877
Pole 2 (Hz) (VCM only)	0 - 1e+09	100000.000
Zero 1 (Hz)	0 - 1e+09	916.445
Zero 2 (Hz) (VCM only)	0 - 1e+09	2250.091

Copy values – Click this button to copy the compensation settings values.

You can use them in your custom code example for **VCM**:

```
#define Pole0 487.841
#define Pole1 4822.877
#define Pole2 100000.000
#define Zero1 916.445
#define Zero2 2250.091
```


or **PCCM**:

```
#define Pole0 24659.727
#define Pole1 4822.877
#define Zero1 882.364
```

6.2 Modulator tab


The **Modulator** tab defines the configuration for high-level parameters of PWM instances.

Voltage



Tabs/Parameter configuration

Peak Current



6.2.1 PWM instance table

The **PWM instance** table displays information about allocated PWM resources.

- **High/Low side switch output** – Corresponding assigned pins.

6.2.2 PWM

The **PMW** settings parameters are applied to all PWM instances. The diagram on the right side illustrates the control loop operation replotted for **VCM** and **PCCM**. At the bottom, the dynamically-replotted PWM ON/OFF scheme for the HS and LS switches depending on the time scale with marked PWM period, Duty cycle, and dead times. The time change of the inductance current is on the top of the scheme. In **PCCM**, the slope generator curve, ADC and Controller blocks present the control loop operation.

Parameter	Description	Range	
Enable high resolution	Enables the PWM High resolution mode	True/False	VCM – True PCCM – False (Read-only)
Dead time rising	Dead time delay for HS	1-1e+09 ns	100 ns
Dead time falling	Dead time delay for LS	1-1e+09 ns	100 ns
Duty cycle min	Minimum modulation duty cycle	Read-only	0%
Duty cycle max	Maximum modulation duty cycle	1-100%	90%
Passive level output	Behavior of PWM outputs with passive PWM	Low High High impedance	Low

6.2.2.1 Comparator (CMP)

The **Comparator (CMP)** group is available only in **PCCM**.

Parameter	Description	Range	Default
Blanking time	The time period when input is ignored to avoid switching transient	0-1000 ns	400 ns

6.2.2.2 DAC settings

The **DAC settings** group is available only in **PCCM**.

Tabs/Parameter configuration

Parameter	Description	Range	Default
Slope mode	Added by DAC current compensation slope	Stable (HW-based) Responsive (HW-based) Custom (editable)	Stable
Slope value	The decrease rate of the comparator reference voltage; active in custom Slope mode	-3300-0 mV/μs	-151.515 mV/μsec

6.3 ADC tab

The **ADC** tab provides the options to configure ADC channels and protection settings in the respective parts.

ADC		Protection				
Trigger source	Channel	Units	Pin	Underlimit Value (ADC equivalent)	Overlimit Value (ADC equivalent)	
Control loop	Controlled value: Vout	V	0.239	AN_A0	4 V (0.956 V)	6 V (1.434 V)
Control loop	Iout	A	0.5	AN_A6	0 A (0 V)	2.8 A (1.4 V)
Control loop	Vin	V	0.064	AN_A7	12 V (0.768 V)	42 V (2.688 V)
Control loop	Temp	V	1	AN_B5	0 V (0 V)	1.3 V (1.3 V)

6.3.1 Toolbar

The ADC tab toolbar contains **Add** and **Remove** channel buttons. The **Remove** button is active only for the last channel on the list.



6.3.2 ADC channels table

ADC group:

- **Trigger source** – The ISR trigger priority. The options from the dropdown menu: **Control loop** or **Scheduled**. For details, see the middleware documentation: <https://github.com/Infineon/mtb-pwrconv>
- **Channel** – The channel name is auto-set or custom.
The first channel configuration is mandatory for the **Infineon control loop**. The controlled output parameter – **Vout**, and the channel name is defined accordingly.
- **Units** – The units of the respective channel. You can select from the dropdown menu: **V** (volts), **A** (amperes), **°** (degrees), or **Custom**.
- **External gain** – The resulting factor of the signal conditioning on the electrical quantity: either attenuation or amplification. The value range is 0.001 - 100.
- **Pin** – Displays the pin assigned to the channel. The pin assignment can be changed from the Device Configurator.


Protection group:

- **Underlimit/Overlimit** – The protection from the under/over crossing ADC range.
- **Value (ADC equivalent)** – Represents the voltage of the native electrical quantity at the MCU pin after conditioning. The maximum supported ADC value is 3.3 V and the minimum – 0V.

Tabs/Parameter configuration

6.4 Controller tab

In the **Controller** tab, the Power Conversion Configurator configures the controller and displays calculated controller coefficients values.



6.4.1 Block diagram

The block diagram illustrates the hardware and software components for the power converter operation. There are several categories of the blocks as shown in the diagram’s legend on the right side:

- **Active** – clickable option, turned on
- **Callback active** – clickable option, turned on
- **Not active** – clickable option, turned off
- **Read only** – not clickable, illustrative only.

Parameter	Description	Default
Control period	The time required for 1 switching cycle.	5.00µs
Custom Control Loop	Disables default Infineon control loop and enables custom implementation	Disabled
Infineon control loop	Enables default control loop implementation	Enabled
Pre-process callback	Executes a user-defined pre-processing callback function before execution of control loop ISR. The callback name is displayed below. Click it to enter a custom name.	Disabled
Post-process callback	Executes a user-defined post-processing callback function after execution of control loop ISR. The callback name is displayed below. Click it to enter a custom name.	Disabled

6.4.2 Controller

The **Controller** section displays the formula used in the controller and correspondent coefficient values. The compensator type can be either Type III (**VCM**) or Type II (**PCCM**).

Parameter	Range
B0	Coefficient for Type II and Type III compensator
B1	Coefficient for Type II and Type III compensator

Tabs/Parameter configuration

Parameter	Range
B2	Coefficient for Type II and Type III compensator
B3	Coefficient for Type III compensator
A1	Coefficient for Type II and Type III compensator
A2	Coefficient for Type II and Type III compensator
A3	Coefficient for Type III compensator
K	Digital controller gain. Scales the controller output to consider PWM, ADC and pre-ADC scaling gain
G	Value fixed to default

Note: Default values for these coefficients are calculated depending on the control mode: **Voltage** or **Peak Current** (see the examples below).

- **Copy coefficients** – Click this button to copy the controller coefficients.

You can use them in your custom code example for **VCM**:

```
#define B0 0.680625
#define B1 -0.614837
#define B2 -0.679306
#define B3 0.616156
#define A1 1.637124
#define A2 -0.446365
#define A3 -0.190759
#define K 258.891213
#define G 1.0
```

or **PCCM**:

```
#define B0 1.915586
#define B1 0.052375
#define B2 -1.863211
#define A1 1.859155
#define A2 -0.859155
#define K 1.046025
#define G 1.0
```

6.4.3 Ramp

The **Reference Ramp** diagram next to the ISR component illustrates the Target update depending on the **Ramp update period** and **Ramp slope**.


Ramp settings

Parameter	Description	Range	Default
Ramp update period	Period required for ramp generator function execution	1-50 ms	1 ms
Ramp slope	Maximal speed of reference value change over time	1-1000 mV/ms (or counts)	1 mV/ms (or counts)


Tabs/Parameter configuration

6.5 Bode plot

The **Bode plot** is a set of graphs that allow assessing a given power conversion design. The graphs are **Gain plot** (magnitude) and **Phase plot** of a transfer function versus frequency. The gain expressed in decibels and phase in degrees are plotted versus frequency using semi-logarithmic axes. A plot set consists of the **Plant**, **Compensator**, and **Open loop** series.



6.5.1 Toolbar




The **Bode plot** toolbar consists of the **Hide/Show legend**; **Zoom in**; **Zoom out**; **Reset zoom** commands.

You can also zoom or move a graph using the mouse. With additional modifiers, you can zoom only the **X** axis (**Shift + Wheel**) or **Y** axis (**Ctrl + Wheel**).

6.5.2 Legend

The **Legend** provides an explanation of displayed graph data and allows for the customization of this information. Select a respective option in the **Legend**, to display the various subsets of series.

Tabs/Parameter configuration



The following options are available:

- **Show plot for poles and zeros** – Check this box to compare the output for the manual and auto compensation settings. If the respective manual and auto compensation settings values are not equal, the series will not overlap, and an alternative set with a dash line series can be clearly visible.
- **Show zero line** – Enable this option to reveal a vertical static line that indicates the **X** coordinate where the open loop series intersects with the 0 dB **Y** axis value, as well as the target Phase margin.
- **Show drag line** – Enable this option to display a vertical draggable line that presents the values of the bode plot series at their intersection with the line at a certain frequency. This line can be moved using the mouse or, if it is beyond the **X** axis range, to make it visible, double-click the chart area.
- **Show phase vs gain series** – Check this box to additionally showcase the phase series on the **Gain plot**. The label [**Phase**] will be included in the legend for differentiation.
- The **X-axis range** remains consistent for both the **Gain** and **Phase** plots and can be modified by selecting the desired min and max values from the dropdown menus. The widest available range spans from 100 Hz to 1 MHz. The Y-axis range adjusts dynamically to ensure the visualization of all series.

Version changes

7 Version changes

This section lists and describes the changes for each version of this tool.

Version	Change descriptions
1.0	New tool.

Revision history

Revision history

Revision	Date	Description
**	2024-11-28	New document.

Trademarks

All referenced product or service names and trademarks are the property of their respective owners.

Edition 2024-11-28**Published by****Infineon Technologies AG****81726 Munich, Germany****© 2024 Infineon Technologies AG.****All Rights Reserved.****Do you have a question about this document?****Email: erratum@infineon.com****Document reference****002-39930 Rev. ******Important notice**

The information given in this document shall in no event be regarded as a guarantee of conditions or characteristics ("Beschaffenheitsgarantie")

With respect to any examples, hints or any typical values stated herein and/or any information regarding the application of the product, Infineon Technologies hereby disclaims any and all warranties and liabilities of any kind, including without limitation warranties of non-infringement of intellectual property rights of any third party.

In addition, any information given in this document is subject to customer's compliance with its obligations stated in this document and any applicable legal requirements, norms and standards concerning customer's products and any use of the product of Infineon Technologies in customer's applications.

The data contained in this document is exclusively intended for technically trained staff. It is the responsibility of customer's technical departments to evaluate the suitability of the product for the intended application and the completeness of the product information given in this document with respect to such application.

Warnings

Due to technical requirements products may contain dangerous substances. For information on the types in question please contact your nearest Infineon Technologies office.

Except as otherwise explicitly approved by Infineon Technologies in a written document signed by authorized representatives of Infineon Technologies, Infineon Technologies' products may not be used in any applications where a failure of the product or any consequences of the use thereof can reasonably be expected to result in personal injury.